

**2-Gang Wi-Fi Smart Switch**

EN | JP | DE | FR | IT | PL | SV | NL | ES | PT | RU

**1**

**断电**  
Power off  
Aussschalten  
Éteindre  
Spegnimento  
Zasilanie wyłączone  
Ávstängd  
Uitschakelen  
Apagado  
Desligar  
Включить

必ず電源を切って作業してください。作業中に電気が流れている可能性があります。必ず電源を切って作業してください。

**2**

**配線**  
Wiring instruction  
Verkabelungsanleitung  
Instrucciones de cableado  
Istruzioni per il cablaggio  
Instrukcja okablowania  
Instruktion für Kabeladragnin  
Bedragningsinstruksjoner  
Instrucciones de cableado  
Instruccões de instalação  
Инструкция по проводке

**3**

**下書き取機APP**  
eWeLink アプリをダウンロードしてインストール  
Download the eWeLink App  
eWeLink APP herunterladen  
Télécharger la eWeLink application  
Scarica la eWeLink App  
Pobierz eWeLink App  
Ladda ner eWeLink App  
Download de eWeLink App  
Descargar la eWeLink aplicación  
Baixe o eWeLink App  
Скачать eWeLink приложение

**4**

**上电**  
電源を入れます。  
Power on  
Einschalten  
Allumer  
Accensione  
Zasilanie włączzone  
Slå på  
Ström op  
Encender  
Ligar  
Включить

**5**

**添加设备**  
デバイスの追加  
Add device  
Ajouter l'appareil  
Aggiungere il dispositivo  
Dodaj urządzenie  
Lägg till en enhet  
Apparaat toevoegen  
Adicionar o aparelho  
Добавить устройство

**6**

**设备安装**  
設備の取付  
Equipment installation  
Ärusrüstung installation  
Installation of equipment  
Apparecchiatura installazione  
Wyposażenie instalacja  
Installation av utrustning  
Utrustning installation  
Instalación de equipo  
Instalação de equipamento  
Монтаж оборудования

**7**

**User Manual**

<https://sonoff.tech/usermanuals>

**8**

**FCC compliance statement**

1. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.

**9**

**ISD Radiation Exposure Statement**

This equipment complies with ISD radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

**10**

**ISD Radiation Exposure Statement**

This equipment complies with ISD radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

**11**

**ISD Radiation Exposure Statement**

This equipment complies with ISD radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

# SONOFF

## 松 诺 技 术

**物料名称 : DUALR3 & Lite 快速指南 V1.5**

**材料工艺 : 105g铜板 四色印刷 手风琴12折页**

**尺寸规格 : 展开: 540x58mm 折后: 45x58mm**

**编制日期 : 2023.09.20**

**备注 :**

**物料名称 : DUALR3 & Lite 快速指南 V1.5**

**材料工艺 : 105g铜板 四色印刷 手风琴12折页**

**尺寸规格 : 展开: 540x58mm 折后: 45x58mm**

**编制日期 : 2023.09.20**

**备注 :**

© 2023 Sonoff Technology Co., Ltd. All rights reserved.

Shenzhen Sonoff Technologies Co., Ltd.

1001, BLDGS, Lianhua Industrial Park, Shenzhen, GD, China

ZIP code: 518000 | Website: sonoff.tech

Service email: support@sonoff.com | MADE IN CHINA

FC | CE | RoHS | PSE | 10 | TÜV Rheinland | CERTIFIED